


Raise wingtips to this angle ($\approx 62^\circ$) so that the tips are 7" apart as shown.
 -Same angle for stabilizer tips.



Rib shape on 1/16 grid.

Cut this rib shape out and iron it onto a piece of hard balsa to make a template for cutting out the ribs. (The small ribs for the Stabilizer.)

